

## Installing a Drip Sweep

- When installing a drip sweep on a Signature Pivot Door, you will first want to place a small amount of drip sweep between the pivot channel and the wall or panel.
- Then trim the sweep so it does not contact anything as the door opens.
- Once enough of the sweep has been trimmed, use silicon caulking to adhere the sweep to the glass.

